

Improving UV Coating Results with Corona & Plasma Surface Preparation

UV coatings are a great choice for high value applications where scratch resistance and surface performance are essential. While traditional UV lamps are still used, the advancement of LED curing technology has improved operational efficiencies for numerous applications. This article will review the importance of properly preparing surfaces for bonding with a variety of in-line surface treating technology options.



Innovative People. Ensuring Your Treating Success.

Improving UV Coating Results with Corona & Plasma Surface

There are a host of factors that contribute to the success of UV coating applications. Pamela Lee, Senior Product Manager of Excelitas OmniCure Area Curing Product Line, says, "Successful curing of UV materials is dependent on a number of factors. One of the most critical is material compatibility (of the adhesive, coating or ink) with the UV LED equipment, as polymerization only occurs when the absorption spectra of the photo initiators match the peak wavelength of the UV output. While the performance of the UV LED equipment is important (peak irradiance, optical output, thermal performance, reliability), other process parameters also influence cure – exposure times, working distances, and pre/post treatment. Depending on the application, surface treatment can significantly help improve adhesion."

Jennifer Heathcote, Business Development Manager at GEW, notes that users of curing equipment sometimes focus on the wrong issue when adhesion issues arise. "When manufacturers contact GEW regarding adhesion issues, they often believe they are not fully curing. They naturally assume something is wrong with the UV curing system. In reality, the polymer is typically cured, but due to lack of surface energy, it is simply not physically possible for the UV cured polymer to adhere to the underlying material. Increasing surface energy through treatment is the only resolution."

With this important emphasis on preparing a surface for bonding, let's explore surface preparation options.

Why Surface Preparation Is Needed

Many surfaces that are coated have inherently low surface energy making them hydrophobic. This inhibits their ability to bond with coatings, adhesives and inks. In addition to low surface energy, lack of bonding sites and surface contamination can also contribute to poor bonding results.

GEW's Jennifer Heathcote explains, "Surface treatment is closely aligned with the success of a UV curing application. When molecules in a UV formulation are exposed to ultraviolet energy, they crosslink to form a polymer. The goal is to fully cure the polymer while also delivering the desired level of adhesion for the end use application. This only occurs when the surface energy of the substrate, media, construction, or part is greater than the surface tension of the applied chemistry."

To increase surface energy and promote bonding, manufacturers employ surface preparation methods such as liquid primers, chemical etching, and mechanical preparations. While these may be suitable for some applications, many manufactures struggle with these processes because they involve hazardous materials, manual application, or take place off-line. They may also find them expensive, inconsistent and time-consuming when compared to automated in-line surface treatment using corona, plasma or flame technology.

Which Technology Is Best For Your Application?

Determining which technology is best for your application begins with properly defining your application. The first criteria is the type of surface to be treated. If it is a film being processed on a converting line (such as flexible packaging) or a shaped object with dimension, different discharge technologies can be used.

Corona Is King for Treating Films

Films can be treated with corona, plasma, flame or ozone to increase surface energy, wettability and bonding results. Most applications use corona treating as it is a highly effective and very economical option. Gas plasma can be used in rare cases where surfaces are not responsive to corona treatment; flame can be used for high speed paperboard applications to remove fibers or high speed foil applications to remove oils; and ozone (along with other technologies) is used with extrudates for extrusion coating applications.

Corona is an ionization of gas and the process cleans and increases surface energy by oxidizing a film's surface and removing contaminants. Corona treatment systems are available to treat both conductive and non-conductive films and may be designed to treat either the complete width of film or sections of the film. Most coating applications would require the entire width of the film to be treated.

Enercon's VP of Application Engineering, Tom Gilbertson, advises corona treater users to measure applied treatment in watt density. "The kW power level of a power supply determines how much energy is supplied to the corona treater. However, applied treatment is most accurately measured in watt density. Watt density is a calculation which takes into consideration the width of the treatment, line speed and power level. Calculating watt density is particularly useful when treating the same type of film on multiple lines with different widths or line speeds."

That being said, it should be noted that not all films respond the same to corona treatment. As you'll see in Chart 1, corona treatment at a specific watt density produces different surface energy results for PET, PS, and PP respectively. The surface energy results you see are recorded in dynes which is a measurable unit of surface wettability. As previously noted, for successful bonding the energy of a surface must be significantly higher than the surface tension of the coating.



It is best practice to experiment with the level of treatment that provides you with the best adhesion results. A rule of thumb to keep in mind is that more power is not always better. Strive for using the least amount of power that makes your application successful.

Treating Objects Requires Different Technology

Unlike film, which is flat and corona treated in-line on coating lines, dimensional objects come in all shapes and sizes and may be flat or have undulating surfaces. For these applications, air plasma treaters with special discharge heads are used.

Before we go into more details on object treating, you may be asking what's the difference between corona and plasma. Technically corona is a form of air plasma. In our experience, we have found that that when the term atmospheric plasma is used in the film extruding and converting industries, it refers to a plasma that includes an additional noble gas to create an effect not possible with corona. When the term atmospheric plasma is used in the treatment of dimensional objects, the industry is referring to an air plasma without the addition of any gas other than air. Variable chemistry atmospheric plasmas are available for treating objects, although in most cases an air plasma treatment is sufficient.

Wilson Lee, Enercon's Business Development Manager for surface treating objects, explains how plasma improves surface energy, "Air plasma surface treaters clean, etch and functionalize surfaces to prepare them for bonding with coatings. In cleaning, we are eliminating static charges, which removes statically held dust and other materials. Most organic and some inorganic contamination is also removed. The etching effect microscopically transforms a smooth manufactured surface into a surface with more bonding sites. This increases the usable bonding surface area to improve overall bond strength. Functionalization, sometimes called activation, describes the addition of hydroxyl or carboxyl groups to the outermost molecular layers of the surface. By adding these polar groups, you increase the overall surface energy and the ability for inks, coatings and adhesives to improve their bond to the modified surface."

Blown-arc, Blown-ion & Flame Plasmas

Blown-arc air plasma (photo) is formed by blowing atmospheric air past two high voltage power electrodes. The electrical discharge positively charges the ion particles surrounding it. Through direct contact, these particles positively charge the treated area of the object's surface. This makes the surface more receptive to any applied substance such as inks. Blownarc plasma cannot treat metallized or conductive surfaces, but is highly effective on a wide variety of plastics including PE, PP, PET, nylon, vinyl, polystyrene, polycarbonate, PVC and all other types of thermoformed and thermoset plastics.



Blown-ion plasma (photo) creates a high velocity concentrated stream of charged ions that provides powerful treatment for both non-conductive and conductive surfaces. It is ideal for higher line speeds, materials that may not be responsive to other treatments, and for reaching small areas that are difficult to access.

Flame surface treating is also another option for in-line treating. Flame treaters are used for high speed lines on surfaces that are capable of withstanding the additional heat created by the flame.

Integrating Plasma and Flame Systems

While the useful effect of treatment may last hours, days or even weeks depending on the application, it is an industry best practice to apply coatings as soon as possible after treating. This provides a fresh and optimized surface. Plasma and flame treaters are very versatile in their ability to be integrated into new or existing lines with conveyors, indexing systems, and robotics.

However it's the consistency and repeatability these technologies offer that make them so popular. "In-line plasma and flame treating provide an automated, repeatable and consistent surface preparation solution that effectively and economically improves throughput and quality control," says Enercon's Wilson Lee.